

Product 512323



512323 Active holder with cig-plug. With tilt swivel.

The active holder charges your Xperia Pro when it is in the holder. The holder is attached onto a tilt swivel and can be adjusted in order to avoid light reflection. Connects to the vehicle's cigarette lighter socket, 12/24 Volt. Attach onto a ProClip Mounting Platform.

EAN: 7320285123236

NEW!

Under development!

Item no 512323 fits:

Sony Ericsson Xperia Pro

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.

2. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Screw a few turns on the screw, just so the thread starts to pull. Pull the holder toward you and hold it slightly tensed, in the same time tighten the screw so the holder is pulled toward the tilt swivel. Tighten the screw until the holder is firmly in place, but still can be adjusted.

3. To place the device in the holder: Place the lower part of the device in the holder, then press the device forwards and downwards so it snaps into place in the holder. To remove the device from the holder: Press downwards on the upper part of the device, in the same time pull the the device out and up from the holder.

4. The holder is in place.
